

Connection Diagram Lead-902010 Kit



If false alarms are frequently occurring - and poor transceiver location or fitting can be eliminated - detection sensitivity can be reduced using the trim pot underneath the QC label

Note: Blue Trigger wire must be supplied with a voltage to activate the Speaker.



